



Installation instructions

*You wood like it*



Meant for Van Speijck Exclusive floors.

PROCEED WITH A VISUAL INSPECTION OF THE PLANKS BEFORE INSTALLATION. ONCE INSTALLED, THE PLANKS ARE CONSIDERED ACCEPTED BY THE INSTALLER AND THE OWNER.

PLEASE READ THE ENTIRE INSTALLATION INSTRUCTIONS BEFORE PROCEEDING WITH THE INSTALLATION. OWNER / INSTALLER RESPONSIBILITY!

Hardwood flooring is a beautiful and unique product of nature, which is characterized by distinctive variations in grain and color. These natural variations in color and grain are not flaws, but are a part of the natural beauty and uniqueness of hardwood flooring. These inherent variations should be expected and serve to enhance the natural beauty and enduring charm. Van Speijck Exclusive floors are manufactured in accordance with accepted industry standards, which permit a defect tolerance not to exceed 5%. The defects may be of a manufacturing or natural type.

- The installer assumes all responsibility for final inspection of product quality. This inspection of the whole flooring should be done before installation. Carefully examine the flooring for color, finish and quality before installing it. Use reasonable selectivity and hold out or cut off pieces with glaring defects whatever the cause. If the flooring is not acceptable, contact your dealer immediately.
- Before beginning installation of any hardwood flooring product, the installer must determine that the environment of the job site and the condition and type of the subfloor involved are acceptable, ensuring that it meets or exceeds all requirements which are stipulated in the Van Speijck installation instructions which follow. Van Speijck Exclusive declines any responsibility for job failure resulting from or associated with inappropriate or improperly prepared subfloor or job site environment deficiencies.
- The use of stain, filler or putty stick for the correction of defects during installation should be accepted as normal procedure.
- Should an individual piece be doubtful as to grade, manufacture or factory finish, the installer should not use the piece.
- When Van Speijck Exclusive hardwood flooring is ordered, a 5% allowance factor, depending on layout, must be added to the actual square meter amount needed. (Diagonal installations and/or board width of 200mm and over may require up to a 10% allowance factor.)
- Please note that engineered wooden floors must be installed in environments of 40% to 65% relative humidity to prevent possible damage not covered by warranty. Installation of a humidifier or dehumidifier may be necessary. The floor is designed to perform in an environmentally controlled structure. Warranty exclusions are, but not limited to, surface checking resulting from low humidity, mildew or discoloration resulting from extreme sub-floor moisture. Keep in mind that if the relative humidity drops below 30% for extended periods, the flooring could shrink and expand causing surface crack, split, bow, crook or delaminating.
- For Van Speijck warranty, flooring area's larger than 75m<sup>2</sup>/ 800 sft and /or containing subfloor heating heat sensors, Fidbox for example, are required. Note: Keep a record in your flooring passport of all your readings for later reference and warranty enquiries. We strongly recommend you keep a record of your moisture and humidity readings prior to and after installation. These measurements will be required by the supplier and manufacturer if there are any future problems.
- The subfloor must be checked for moisture content by an appropriate testing method. Test results must be recorded and available for review when asked for.

## JOB SITE INSPECTION

- This type of flooring can be installed below, equal or above ground level. Do not install in a bathroom.
- In a new construction, hardwood flooring should be one of the last items installed. All work involving water or moisture (plumbing, acoustical ceilings, dry wall taping, etc.) should be completed prior to wood flooring being installed. Heating and air systems should be fully operating maintaining a consistent room temperature at 18°C to 25°C (64-77° F) and a constant relative humidity of 40% to 65%.
- Flooring should not be delivered until the building has been closed in and cement work, plastering, painting and other materials are completely dry. Concrete and plaster should be cured and at least 60 days old. Check basements and underfloor crawl space to be sure that they are dry and well ventilated to avoid damage caused by moisture.

## ACCLIMATION

- Handle with care. Do not stand on ends. Store Van Speijck flooring in a dry place being sure to provide at least a 4" air space under and around bundles.
- Do not store directly on concrete or near outside walls. Each bundle should be opened and installation cannot begin before the moisture content of the plank is within 2% of the substrate in the installation area. Van Speijck recommends to rotate the planks while acclimating to ensure proper air circulation.
- Flooring should be at the job site at least 72 hours or as long as necessary to meet minimum installation requirements for moisture content.
- The humidity level of the house must be maintained between 40% and 65% all year long. Wood is a hygroscopic product which reacts to humidity level variations. During summer, where the humidity level is at its highest point, the wood has a natural expansion and absorbs the humidity, these variations must be dealt with adequate dehumidification. As for winter, when the heating system is working, the humidity level is lower. It is then recommended to use a humidifier to minimize the extreme effects of shrinkage.

## INSTALLATION METHODS (Floating, stapled and Glued down) AND APPROVED SUBFLOORS

Type of subfloor:	Floating	Stapled	Glued
Plywood 5/8" –OSB 23/32" (truss/joist of 16" c/c or less)	YES	YES	YES
Plywood 3/4" T&G –OSB 23/32" (truss/joist of 19,2" c/c or less)	YES	YES	YES
Concrete	YES	NO	YES
Ceramic tiled floor, terrazzo, slate and marble	YES	NO	YES
(Concrete) Radiant Subfloor heating	YES	NO	YES
Radiant heating (plywood)	YES	YES	YES
<b>Type of plank/ pattern:</b>			
Plank – Project/Builder – Premium	YES	YES	YES
Herringbone/ Chevron	NO	YES	YES
Patterns	NO	YES	YES
Plank - XL	NO	YES	YES

Note: on the XL we strongly advise a Glue and Nail-Down combination!

## SUBFLOOR CONDITIONS

- CLEAN - Scraped or sanded, swept, free of wax, grease, paint, oil and other debris.
- HORIZONTAL / FLAT – Maximum tolerance of 5mm over 3 meter, or 3mm over 2 meter.
- Sand high areas or joints. If the floor is glued, fill the low areas with a latex additive cement surfacing product with a minimum resistance to compression of 20 000 kPa.
- Concrete Slabs (regardless of existing floor covering): Use an approved calibrated concrete Moisture Meter as a preliminary measurement for moisture. Concrete subfloors must be finished at least 30 days before performing a test. Acceptable verification methods: Perform a polyfilm test. Tape down 60cm x 60cm polyfilm squares (a clear garbage bag or plastic drop cloth will do) in several places on the floor. Wait 24-48 hours, and then check for the appearance of condensation on the inside of the bag or plastic for a darkening on the concrete subfloor. Either occurrence signals the likely presence of excess moisture, which needs other measures with the concrete moisture meter Tramex. The measure must not climb over 4,5 on the superior graduation. The floor can be glued directly on concrete with a compression resistance of at least 20 000 kPa (3 000 lb/in<sup>2</sup>).
- Wood Substrates: Test the moisture of the wood substrate using a calibrated moisture meter approved for testing wood moisture according to the meter manufacturer. The reading should not exceed 12%, or read more than a 4% difference than moisture content of products being installed.

## RADIANT SUBFLOOR HEATING

All the Van Speijck Engineered Flooring is tested and approved for installation on Radiant heating. Please note that Solid flooring is not tested and approved.

Please read our "Subfloor Heating Guide". This is Extremely important. Not working according these guidelines can void the warranty on your Van Speijck Exclusive Floor! It is available on our website and can be provided by your dealer.

## STEP BY STEP INSTALLATION INSTRUCTION (Glued down application)

### STEP 1 – Establish a starting line

- For best visual effect, it is recommended that flooring be installed parallel to the longest wall in the room.
- Using a chalk line the area between the wall and the chalk line becomes your working area for starting installation, and your last installation area for completing the installation.

### STEP 2 – Spread the adhesive

- Apply the recommended adhesive with a trowel according to the manufacturer installation instructions (found on the adhesive pail) for the specific adhesive that is being used.

### STEP 3 – Install the planks

- Always select your planks with care. The more deeply colored planks should be installed where they are less visible. Pieces with flaws should be recut.
- Using the working area to install your flooring, line up the first strip with the tongue facing the wall, then press the strip into the adhesive and against the holding block.
- Leave 6mm between the wall and the end of each strip in each row.
- Start the second row with a strip of at least 15cm shorter or longer than the strip used in the first row. This will avoid aligning or clustering the end joints.
- Continue with the subsequent rows in the same manner.
- To avoid shifting or gapping of the planks during installation, use 3M blue tape to hold them together. Remove the tape within 24 hours. Avoid use of masking tape, which leaves an adhesive residue and may damage the finish.
- When you get to the final row you will likely find it necessary to rip-saw the planks to fit against the wall. Install using the pry bar and leave 6mm minimum expansion spaces.

### STEP 4 – Once installation is finished

- Always keep a few spare planks from your initial installation for possible repairs in a sealed carton and properly stored
- Apply a coat of Van Speijck Maintenance Oil.
- Wait 24 hours before moving furniture and appliances back into the area where flooring was installed.

## REQUIRED TOOLS FOR PROPER INSTALLATION

### Power Tools

- Table Saw, Electric Miter Saw, Band Saw, Chop Saw, Power Jamb Saw, or Jig Saw

### Hand Tools

- Broom and dust pan or Vacuum
- Tape Measure
- Moisture meter (wood, concrete or both)
- Chalk line & chalk
- 3M Blue Tape
- Hand saw
- Hammer
- Rubber mallet
- Tapping block
- Pry bar
- Filler stick and Touch-up marker
- Hardwood Floor Cleaner

### Additional Tools for Glue-Down

- Recommended Adhesive & Adhesive Remover
- Trowel (Follow adhesive manufacturer's instruction)

### Additional Tools for Staple-Down Installation

- Pneumatic Stapler/Nailer
- Staples/Flooring Cleats
- Drill

### Additional Tools for Floating Installation

- 6 mil Polyethylene Vapor Barrier
- Foam Underlayment
- Floating Floor Glue

## STEP-BY-STEP INSTALLATION INSTRUCTION (Nailed/stapled down application)

### Set-up and Use of Pneumatic Staplers and Nailers

- Read and follow the manufacturer's instructions for complete set-up and operation of equipment.
- Make sure the adapter size for the pneumatic stapler or nailer matches the thickness of the flooring being installed and that the tool's adapter seats properly in the tongue of the flooring.
- Pneumatic nailer: Air pressure should be adjusted adequately for each species of hardwood floor installed and checked regularly (always try it before using).

### STEP 1 – Establish a starting line

- Using a chalk line, draw a guideline.
- It is very important to start straight and square.

### STEP 2 – Install the floor

- Always select your planks with care. The more deeply colored planks should be installed where they are less visible (i.e. in a closet or under the refrigerator). Pieces with flaws should be recut.
- Use the longest, straightest planks available for the first row.
- Install the first row of flooring with groove facing starter wall.
- The first few rows must be nailed down by hand rather than with the nailing machine because of the vertical wall obstruction. Nailing interval should be at 15cm. Leave 6mm between the wall and the end of each strip in each row.
- Start the second row with a strip of a least 15cm shorter or longer than the strip used in the first row. This will avoid aligning or clustering the end joints.
- When the area is free from wall obstruction, you can repeat the installation using a pneumatic stapler.
- It is also likely that you may have to rip saw the planks to fit the final row against the wall. Leave 6mm minimum expansion spaces.

## STEP-BY-STEP INSTALLATION INSTRUCTION (Floating application)

Important notice regarding expansion space: It is important to include an expansion space of 1.5cm between rooms (ex: hallway adjacent to a bedroom). You will need to fill this space with a molding. Same rule applies for rooms exceeding 9 meter, you will also need an expansion space and a molding.

### STEP 1 – Install underlayment's

Install 6 mil Polyethylene vapor barrier over entire flooring surface. Overlap sheets of Polyethylene 40cm and tape together creating airtight seal. Run the vapor barrier 3 to 4cm up the walls and secure in place with tape. Using underlayment, roll out one roll at a time over the vapor barrier. There are many types of underlayment's available today. The use of acoustical underlayment will improve the feel and sound transmission of your flooring.

### STEP 2 – Preparing the starter rows

It is very important that enough expansion gaps are kept between the flooring and all the walls. This is done by placing 6mm spacers every 20cm apart around all vertical walls. Measure the width of the room – perpendicular to the direction you intend to install the flooring. The last row of flooring should be no less than 4cm wide. If it is less, you should rip-saw the starter row narrower. Leave 6mm between the wall and the end of each strip in each row. Start the second row with a strip of at least 15cm shorter or longer than the strip used in the first row. This will avoid aligning or clustering the end joints.

### STEP 3 – Gluing the floor

In a floating floor installation, the flooring is not glued or nailed to the underlayment, but is glued in the board's side and end grooves only. This is achieved by applying a bead of glue on the upper side of the groove along the entire length and on the end of each plank with T & G glue. Turn the board upside down when applying the adhesive to achieve proper application, when the board is turned again for installation with the finish side up, this will allow the adhesive to flow down and give better coverage. Do not apply adhesive on the top of the tongue.

Install the first row of flooring with groove facing starter wall. Use a tapping block and a mallet to gently push or tap the glued planks together until no gaps are seen and making sure that end joints are square. At the end wall use a pry bar, if needed, to pull the ends of the boards tight. Continue laying the floor on top of the underlayment, working left to right, tapping the planks tight together. Make sure to continue using 6mm spacers

along the wall throughout the installation. To avoid shifting or gapping of the flooring during installation, lay perpendicular planks of 3M blue tape to hold the planks together. Remove the tape within 24 hours. Avoid use of masking tape, which leaves an adhesive residue and may cause damage to the finish.

The last row will most likely require cutting to width but it should be no less than 4cm wide. To do this, place a full row of planks on top of the last row installed. Insert a 6mm spacer against the wall, and using a full width strip, trace distance from wall onto final row. Cut planks for final row to designated width. Apply glue and pull into place with a pry bar.

Allow floor to dry for a minimum of 12 hours before removing all the spacers and allowing foot traffic. Finally, install the transition pieces, baseboards and/or, quarter round molding's.

## COMPLETING THE JOB – ALL INSTALLATION

- Optional: clean the floor and apply a coat of Van Speijck Maintenance Oil.
- Please ensure that any adhesive on the finish is cleaned before leaving.
- Install transition pieces.
- Inspect final floor for nicks or minor gaps and fill with appropriate color wood putty.
- Use plywood or hardboard when moving heavy appliances or furniture across floor.

"INSTALLATION IMPLIES ACCEPTANCE."

NO WARRANTY WILL BE OFFERED FOR APPEARANCE RELATED CLAIMS  
ONCE THE PRODUCTS ARE INSTALLED.